

Climatic conditions for carrying out checks and maintenance

- the environment temperature must be between +5 °C to +40 °C
- the surface temperature of the outdoor furniture and accessories must not be lower than 3 °C above the dew point
- the relative air humidity must not exceed:
 - < 70 % for wooden parts
 - 80 % for other parts

INSTRUCTIONS FOR REGULAR CHECKS AND MAINTENANCE**All Parts**

- wash with hot water with the recommended concentration of a suitable detergent using a soft fabric cloth or a sponge,
- remove oil or grease mark by using an organic dissolvent agent,
- rinse the surface with clean water after cleaning,
- wipe dry.



Do not use sharp items or abrasive agents for steel surfaces as they might cause damage to the surface.

Metal Constructions

- check the surface regularly,
- if you find damage, order a repair with the seller/manufacturer or perform a local repair, if reasonable to do so:
 1. clean the affected area mechanically, the surface must be clean and dry
 2. degrease the area using technical alcohol or petrol or stains
 3. roughen the surface with P120 sandpaper
 4. apply zinc paint with high content of zinc – at least 96 %
 5. after drying out, remove any excess paint using P280 sandpaper and roughen the surface finely
 6. apply powder paint mixed with a dissolution agent following the manufacturer's instructions.



The same paint tone may temporarily differ from the original colour.

Wooden Parts












- check for the damage of boards or slabs (if damaged, order new parts or have them replaced by the manufacturer),
- check the roughness of the wood (for ensuring a smooth surface, treat with P150 sandpaper),
- before the start of the season, renew coating of parts treated with teak oil or a glaze:
 1. clean the surface using water with a mild detergent
 2. sand the wood using P150 to P220 sandpaper
 3. apply two coats of oil or glaze with a sponge

Polycarbonate Parts

- check for sagging or deformation of boards (if any deformation is established, the damaged parts must be replaced immediately),
- check the sealing of cover profiles around the boards (damaged sealing must be replaced immediately).

Shading Canvas, covers of Outdoor Mattresses and Pillows

- remove smaller impurities by using a soft brush or a wet soft fabric cloth,
- remove dust from upholstered parts by using a soft brush or a vacuum cleaner,
- check on the label of the cover if suitable for washing in a washing-machine; usually possible up to a max. of 40°C, with a lower spin cycle,
- do not use a tumble dryer for drying,
- check the label if the cover is suitable for ironing; usually possible up to a max. of 110°C, no steam recommended.

											
CREVIN		X			X		X		X		X
KORTEXIN			X	X		X	X		X		X
SUNBRELLA			X								X
BATYLINE			X				X				X
HEDVA	X					X		X			X
SIO LINE			X	X		X	X		X		X

PUR Foam Mattresses

- remove smaller impurities by using a soft brush or a wet soft fabric cloth,
- the material is not washing-machine safe.

Fastening materials, Sealing and Rubber Parts

- check their condition and fastening ,
- wash with a solution of alcohol and glycerine (10:1),
 - do not use a petrol, benzene, turpentine, crude oil or similar based solution
- if needed, replace, tighten or seal the respective parts by using appropriate tools.

Locks and Moving Mechanisms

- check their functionality,
- treat the locks and mechanisms using a Vaseline spray or gentle lubricating oil,
- lock and unlock several times so that the oil can spread into the whole mechanism .

Water Taps, Sinks and Other Optional Parts of the Outdoor Kitchen

- please follow the manufacturer's instructions contained in the attached manuals

Foundations

- check the firmness of anchoring (earth screws, threaded rods with chemical anchors),
- check the condition of concrete footings / walls.



Any cracks or other mechanical damage of the concrete foundations must be repaired professionally.

Electrical Installation

- checks and maintenance of electrical installations may be conducted solely by authorised qualified personnel

MEASURES BEFORE THE START OF WINTER

- disconnect the water supply for exterior elements and let out the remaining water from the pipes,
- store mattresses, seat cushions from outdoor foam, removable shading elements and products with outdoor covers in a protected dry space:
 - the products can be damaged if repeatedly exposed to wet conditions without the possibility of drying out properly,
 - the risk of dirt adhering to the fabric and mould growth is high for products that are only rolled or folded and exposed to the weather in winter,
 - failure to comply with this measure is considered as improper storage.

PRESCRIBED TIME INTERVALS FOR PERFORMING CHECKS AND MAINTENANCE

metal, glass and polycarbonate parts	2× per year (before and after the season)
fastening materials, locks and movable mechanisms, rubber	2× per year (before and after the season)
wood and its coating	1× per year (before the season)

Keeping Records of Checks and Maintenance of Street Furniture Located in Public Space

- under the current legislation, records must be kept about the checks and maintenance of street furniture located public space,
- the operator or owner of the street furniture must keep proper and comprehensible records about the performed checks and maintenance (original condition, date of the check/maintenance, final condition), ideally including photo documentation of the condition.

WARRANTY CONDITIONS

The warranty applies to all products by Egoé life a.s., operated and maintained according to the manufacturer’s instructions and the respective legislation.

The warranty applies to any damage caused by or resulting from hidden material or production defects.

The warranty does not apply to defects caused by:

- improper handling or storage, mechanical damage, vandalism, natural wear, natural catastrophes or other weather conditions,
- specific properties of the used materials such as:
 - crack formation or washing out of inner substances in the used wood,
 - uv stability, colour fastness and shrinkage of textile materials.

!	To maintain colour fastness, do not leave products with outdoor textiles permanently exposed to the sun. Colours will fade over time and „color shading“ is not a cause for complaint.
----------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

WARRANTY PERIODS

Galvanised and powder coated steel construction parts. Powder coated or anodised aluminium structural parts.	against corrosion damage	48 months
Seashore areas or areas with a risk of exposure to salty environment – surface treatment category ‘C5-M’ according to ISO 12944-2: Galvanised and powder coated steel construction parts. Powder coated or anodised aluminium structural parts.	against corrosion damage	24 months
Wood parts – tropical woods	against fungus, rotting and mould	120 months
Wood parts – thermized wood, larch, acacia	against fungus, rotting and mould	60 months
Parts made from polycarbonate filling	for maintaining firmness, elasticity and resiliency against hail	60 months
Parts made from HPL	for maintaining firmness and elasticity	24 months
Stainless fastening material	against corrosion damage	24 months